















Part list

 ①×1	 ②×2	 ③×2
 ④×1	 ⑤×1	 ⑥×1
 ⑦×1	 ⑧×1	 ⑨×1
 ⑩×1	 ⑪×1	 ⑫×1


Hardware list




Ⓐ×1




Ⓑ×4+1



Ⓒ×3+1




Ⓓ×3




M6*12

Ⓔ×4+1






M6*35

Ⓕ×10+1




M6*45

Ⓖ×4+1




Ⓗ×1


1



2





3



(E) × 2

4




(F) × 4

[EN] Tighten the screw to 80%.


[FR] Serrez la vis à 80 %.

[DE] Ziehen Sie die Schraube zu 80 % fest.


5



6





7




(E) × 2

8




(F) × 2

9



10




11


[EN] Check if all the screws are securely tightened.

[DE] Überprüfen Sie, ob alle Schrauben fest angezogen sind.

[FR] Vérifiez que toutes les vis sont bien serrées.



12



[EN] The orientation of the 11th mirror is determined based on the actual situation. During installation, only the positions of the 4th and 5th components need to be adjusted.

[DE] Die Ausrichtung des 11. Spiegels wird anhand der tatsächlichen Situation festgelegt. Bei der Installation müssen nur die Positionen der 4. und 5. Komponente angepasst werden.

[FR] L'orientation du 11e miroir est déterminée en fonction de la situation réelle. Lors de l'installation, seules les positions des 4e et 5e composants doivent être ajustées.